


VALVE WITH TANK

Separated-tank solution for towed vehicles



TOWED VEHICLES |



The new design update includes:

- **Easier positioning:**

Valve and Tank **can be installed separately** one to the other.

Their connection is carried out by using hydraulic hoses.

This solves installation problems typical of vehicles with **small installation space availability**.

- **New indication system** of manual operation mode:

A red indicator appears when selecting the manual valve mode **and disappears automatically as soon as the trailer is connected back to a dual-line tractor**.

- **Overpressure protection** for supplementary line:

The **relief valve prevents the pressure in the SL line from exceeding** the safety limit avoiding accidental damages to the system.